

# Cube400V Operating Manual

## Current Sensor Inputs

August 2010




# 1 Safety

This instruction manual gives details of safe installation and operation of the **Cube400V** electricity meter. Safety may be impaired if the instructions are not followed. Labels on each meter give details of equipment ratings for safe operation. Take time to examine all labels before commencing installation. Safety symbols on the meter have specific meanings.



Refer To User Manual



Risk of Electric Shock

## **WARNING**

The meter contains no user serviceable parts. Installation and commissioning should only be carried out by qualified personnel

## **WARNING**

### ***Risk of Electric Shock***

Isolate all inputs and supplies to the meter before connecting the current sensors on the load cables or wiring the sensors to the meter.

## **1.1 Maintenance**

The equipment should be maintained in good working order. Damage to the product should be repaired by the manufacturer. The meter may be cleaned by wiping lightly with a soft cloth. No solvents or cleaning agents should be used. All inputs and supplies must be isolated before cleaning any part of the equipment.

Further information is available at <http://www.ndmeter.co.uk>.

## **1.2 Waste Electrical/Electronic Equipment**


At the end of this products useful life it should be disposed of ONLY via a recycling center as defined by the EU WEEE directive. This product should not be incinerated.

## 2 Display Pages


Measured data is displayed on numerous pages organised in four Standard Menus and two Distortion Menus as follows:

### 2.1 Power Up

The following screen is shown when auxiliary power is first supplied.



### 2.2 Current Menu

Press the  key to select from the available Current Menu pages.



#### Phase Amps

Phase 1 true rms amps

Phase 2 true rms amps.

Phase 3 true rms amps.


This display is updated every second.



#### Peak Hold Phase Amps

The maximum value of displayed phase amps. These are stored in non-volatile memory when the meter loses auxiliary power

Press  and  to reset all three maximums to zero <sup>note 1</sup>.



**Time-Averaged Amps**

The calculated average of phase amps taken over a user definable time period  $T_{VI}$  (10s to 1800s).

A rolling time window is used and the display updated every  $T_{VI}/10$  with the average of the most recent period displayed.




**Peak Time-Averaged Amps**

The maximum value of Time-Averaged amps. These are stored in non-volatile memory when the meter loses auxiliary power

Press  and  to reset all three maximums to zero <sup>note 1</sup>.

**2.3 Voltage Menu**

Press the  key to select from the available Voltage Menu pages.




**Phase Volts**

Phase 1 to neutral true rms volts  
 Phase 2 to neutral true rms volts.  
 Phase 3 to neutral true rms volts.  
 This display is updated every second.



**Line Volts**

Line 1 true rms volts (Phases 1-2)  
 Line 2 true rms volts (Phases 2-3)  
 Line 3 true rms volts (Phases 3-1)  
 This display is updated every second.



**Peak Hold Phase Volts**

The maximum value of displayed phase volts. These are stored in non-volatile memory when the meter loses auxiliary power

Press  and  to reset all three maximums to zero <sup>note 1</sup>.



**Time-Averaged Volts**

The calculated average of phase volts taken over a user definable time period  $T_{VI}$  (10s to 1800s).

A rolling time window is used and the display updated every  $T_{VI}/10$  with the average of the most recent period displayed.




**Peak Time-Averaged Volts**

The maximum value of Time-Averaged volts. These are stored in non-volatile memory when the meter loses auxiliary power


Press  and  to reset all three maximums to zero <sup>note 1</sup>.

2.4 Power Menu

Press the  key to select from the available Power Menu pages.



**System Power**

System Reactive Power (var)  
 System Active Power (VA)  
 System Real Power (Watts)  
 A  symbol after the var value indicates a capacitive load.  
 A negative sign before the var readings indicates export reactive power.




**Phase Watts**

Phase 1 true rms watts  
 Phase 2 true rms watts.  
 Phase 3 true rms watts  
 A negative sign before the watt readings indicates export power.




**System Page 2**

Balance current. (I1+I2+I3)  
 Frequency (Measured on V1)  
 System Power Factor  
 A  symbol after the power factor value indicates a capacitive load.



**Phase VA**


Phase 1 true rms VA  
 Phase 2 true rms VA.  
 Phase 3 true rms VA



**Phase var**

Phase 1 true rms var.  
Phase 2 true rms var.  
Phase 3 true rms var.

A **⚡** symbol after a var value indicates a capacitive load.  
A negative sign before a var reading indicates export reactive power.



**Phase Power Factor**

Phase 1 Power Factor.  
Phase 2 Power Factor.  
Phase 3 Power Factor.

A **⚡** symbol after each value indicates a capacitive load.



**Power Mean Demand (MD)**

The calculated average of the system power values taken over a user definable time period  $T_p$  (1min to 60min).  
A rolling time window is used and the display updated every  $T_p/60$  with the averages of the most recent period displayed.




**Peak Hold MD**

The maximum value of each power MD value. These are stored in non-volatile memory when the meter loses auxiliary power

Press **I** and **V** to reset all three maximums to zero <sup>note 1</sup>.

**NOTE 1:** Meters may be installed with the option to reset all peak hold values using the front keys disabled.

## 2.5 Energy Menu

Press the  key to select from the available Energy Menu pages.



### Real Energy (Wh)

This register accumulates only when real power (kW) is positive (import).

This value returns to 0 when the value exceeds 99999999.

This register is stored in non-volatile memory when auxiliary power is not supplied to the meter.



### Reactive Energy (varh)

Import varh Accumulating register.

This value returns to 0 when the value exceeds 99999999.

This register is stored in non-volatile memory when auxiliary power is not supplied to the meter.




### Apparent Energy (VAh)

Import VAh Accumulating register.

This value returns to 0 when the value exceeds 99999999.

This register is stored in non-volatile memory when auxiliary power is not supplied to the meter.



### Hours Run <sup>Note 2</sup>

This register accumulates time in Hours only while real power (kWh) is above a user set level (see programming section).

This value returns to 0.0 when the value exceeds 99999999.

This register is stored in non-volatile memory when auxiliary power is not supplied to the meter.



**Export kWh** *Note 2*

This register accumulates only when real power (kW) is negative (export).

This value returns to 0 when the value exceeds 99999999.

This register is stored in non-volatile memory when auxiliary power is not supplied to the meter.



**Export kVarh** *Note 2*



This register accumulates only when reactive power (kvar) is negative (export).

This value returns to 0 when the value exceeds 99999999.

This register is stored in non-volatile memory when auxiliary power is not supplied to the meter.

**NOTE 2:** Hours Run, Export kWh and Export kVarh are factory fitted options. If these options are not supplied relevant page(s) will be omitted.

Meters may be supplied with an option to reset energy registers to zero using the front keys.

If the option is fitted, press  and  together and hold for approximately 3 seconds to simultaneously reset all energy registers to zero. Once reset the registers may not be recovered.

## 2.6 Power Quality Menus

**NOTE:** The power quality menus are only available on the **Cube400V** meter with the “Harmonic” option fitted.

To enter/exit power quality display mode press  and  together and hold for approximately 3 seconds.

### 2.6.1 Amps Power Quality Menu

Press the  key to select the Amps Power Quality Sub Menu. Press  or  keys to select the next/previous Amps Power Quality page.



### **Amps Total Harmonic Distortion**


Phase 1 Amps THD

Phase 2 Amps THD.

Phase 3 Amps THD.

This display is updated every second.

THD is scaled as a percentage of the fundamental rms amps value. This example shows 20.0% THD.



### **Amps Individual Harmonics 02-15**



Phase 1 Amps harmonic 02-15

Phase 2 Amps harmonic 02-15

Phase 3 Amps harmonic 02-15.

The harmonics are scaled as a percentage of the fundamental rms amps value. This example shows 10.0% second harmonic.

**2.6.2 Volts Power Quality Menu**

Press the  key to select the Volts Power Quality Sub Menu. Press  or  keys to select the next/previous Volts Power Quality page.



**Volts Total Harmonic Distortion**

Phase 1 Volts THD

Phase 2 Volts THD.

Phase 3 Volts THD.

This display is updated every second.

THD is scaled as a percentage of the fundamental rms volts value. This example shows 20.0% THD.



**Volts Individual Harmonics 02-15**

Phase 1 Volts harmonic 02-15

Phase 2 Volts harmonic 02-15

Phase 3 Volts harmonic 02-15.

The harmonics are scaled as a percentage of the fundamental rms volts value. This example shows 10.0% second harmonic.

**2.7 Display Scaling**

The units, Wh, kWh or MWh and the position of the decimal point for the energy/power displays are automatically set dependant on the **CT** and **PT** settings for the meter.

The nominal 3-phase input for the meter is defined as:

$$W_{nom} = \sqrt{3} \times U_n \times CT$$

Where: **Un** is the nominal Line-Line voltage or PT primary (10V - 440kV).

**CT** is the current sensor nominal primary (5A – 800A)

**Un** and **CT** are set in programming mode.

The display pages are scaled as follows:

**2.7.1 Voltage Scaling)**

PT Setting (Un)	Resolution
10V <sub>L-L</sub> - 80V <sub>L-L</sub>	0.01 V
81V <sub>L-L</sub> - 800V <sub>L-L</sub>	0.1 V
801V <sub>L-L</sub> – 8,000V <sub>L-L</sub>	1 V
8,001V <sub>L-L</sub> - 80,000V <sub>L-L</sub>	0.01 kV
80,001V <sub>L-L</sub> - 440,000V <sub>L-L</sub>	0.1 kV

**2.7.2 Current Scaling**

CT Setting	Resolution
5A	0.001 A
50A	0.01 A
100A	0.1 A
150A	0.1 A
400A	0.1 A
800A	0.1 A

**2.7.3 Power Scaling (W, VA, var)**

PT Setting x CT Setting Un x CT	Phase Power Resolution	System Power Resolution
100VA - 1,400VA	0.1 W	0.001 kW
1,401VA – 14,000VA	0.001 kW	0.01 kW
14,001VA - 140,000VA	0.01 kW	0.1 kW
140,001VA - 1,400,000VA	0.1 kW	1 kW
1,400,001VA - 14,000,000VA	1 kW	0.01 MW
14,000,001VA - 140,000,000VA	0.01 MW	0.1 MW
140,000,001VA – 1,000,000,000VA	0.1 MW	1 MW

**2.7.4 Energy Registers (Wh, VAh, varh)**

PT Setting x CT Setting Un x CT	Resolution
100VA - 1,400VA	.001 kWh
1,401VA - 14,000VA	0.01 kWh
14,001VA - 140,000VA	0.1 kWh
140,001VA - 1,400,000VA	1 kWh
1,400,001VA - 14,000,000VA	0.01 MWh
14,000,001VA - 140,000,000VA	0.1 MWh
140,000,001VA – 1,000,000,000VA	1 MWh

**2.7.5 Miscellaneous**

All Settings	Resolution
System and Phase PF	0.001
Amps and Volts % THD	0.1%
Amps and Volts % Harmonic	0.1%
Frequency	0.1 hz

### 3 Connection

#### 3.1 Mounting In a Panel


Panels should be 1mm to 4mm thick with a square cutout of 92mm (+0.8/-0.0mm). Insert the meter from the front of the panel, slide the panel clips from the rear of the case and push firmly against the panel ensuring even pressure on each clip.

#### 3.2 Pulse Output Connection

The pulse outputs take the form of isolated volt free normally open contact pairs.

The contacts are isolated from all other circuits (2.5kV / 1 minute) and at 50V from pulse 1 to pulse 2.

The pulses can be used as an input to a remote counter, pulse logger, building energy management system etc.



**Pulse Output Connections**

## 3.3 Using Current Sensors


### WARNING

#### Risk of Electric Shock

Isolate all inputs and supplies to the meter before connecting the current sensors on the load cables or wiring the sensors to the meter.

### 3.3.1 CT Polarity

The current sensors MUST be placed on the load cable with the correct polarity. The following diagram shows how each device is fitted on the cable for correct operation:




**NOTE:** If a current sensor is placed on the cable in the opposite orientation the associated phase kW reading will be negative.

The secondary cables also require wiring with correct polarity. The white cable (or black/white) is the negative and should be connected to S2 or CT- on the meter. The black cable is the positive and should be connected to S1 or CT+ on the meter.


#### NOTES:

- The output from these current sensors is a low voltage. It is safe to leave these outputs open-circuit if not connected to a meter.
- The output connections from these current sensors must be individually wired direct to the meter and must not be earthed or connected to any other circuit.
- If the sensor secondary cables require extending, care must be taken to avoid pickup of electrical interference. With suitable low capacitance screened cables, the cable can be extended to 100m or more.
- Examples of suitable cables include Belden 9841, Alpha 6412 and equivalents; also multi-pair versions of these cables.  
This cable must have an insulation rating >250V.

3.4 Standard Connections



3-Phase 3 or 4-Wire (\*Optional Neutral)



Single Phase

## 4 Pulse Outputs

Two isolated pulse outputs are provided for connection to external systems such as Building Energy Management Systems (BEMS), data loggers, remote counters etc.

Pulse 1 is always associated with the active energy (kWh) register.

Pulse 2 is normally associated with the reactive energy (kvarh) register but meters may be supplied with this pulse linked to the kVAh register.

A single pulse occurs for each unit of energy on the display (eg 1 pulse per 0.1kWh). The pulse rate (amount of energy associated with each pulse) and pulse length may be set to suit the external system.

### 4.1.1 Pulse LEDs

Light emitting diodes (LEDs) on the front panel of the instrument remain ON during each associated output pulse.



***Pulse Output Indicators***

## 5 Meter Setup

### 5.1 Programming Menu

To enter programming mode:


Hold  and  together for 5 Seconds.

#### 4-Digit Security Code



This page is only shown if a **security code** greater than 0 is set via serial communication.



Press  or  to select each digit (least significant first)

Press  to move to the next most significant digit.

A correct 4 digit security code is required to access other programming menu pages.


#### Current Transformer Primary






Press  or  to select from the standard list of current sensors.

Press  to accept the set value.

#### Potential Transformer Primary




Press  or  to select from the standard list of PT primaries while **L** is displayed. (List Mode)

Press  or  to increase or decrease the value by 10 while **F** is displayed. (Fine adjust)

Press  and  together to toggle between **L** and **F**.

Press  to accept the set value.

**Power MD Integration Period** *(Note 1)*




This sets the integration period in minutes used for the sliding time window MD calculation for power.

Press **P** or **E** to increment or decrement the value.

Press **I** to accept the set value.

**Current/Voltage Time Ave Period** *(Note 1)*




This sets the integration period in seconds used for the sliding time window average calculation for current and voltage.

Press **P** or **E** to increment or decrement the value.

Press **I** to accept the set value.

**Hours Run Set Point** *(Note 1)*



This sets the instantaneous system kW level above which the Hours Run timer will accumulate.

Below this level Hours Run will remain unchanged.

Press **P** or **E** to increment or decrement the value. The speed of change will increase as the button is held.

Press **I** to accept the set value.

**Pulse Rate**




This sets the amount of energy (kWh) required to trigger each Pulse 1 output.

Pulse 2 is set at the same rate but linked to a different register (eg kvarh).

Press **P** **▲** or **E** **▼** to select the next/previous Pulse Rate from a standard list.

Press **I** **◀** to accept the set value.

**Pulse Length**




This sets the contact closure time for both pulse outputs.

Press **P** **▲** or **E** **▼** to select the next/previous Pulse Length from a standard list.

Press **I** **◀** to accept the set value.

**Pulse Test**



This allows the commissioning engineer to test both pulse outputs and associated circuits without the need of a test load.

Press **P** **▲** or **E** **▼** to start/stop a test pulse stream. The display shows **HLD** (Hold) or **RUN** respectively.

The counter shows the total number of pulses during the test.

Press **I** **◀** and **V** **▶** to reset the test counter to zero.

Press **I** **◀** to accept the set value.

**Note 1.** Some setup screens are only available on meters with corresponding measurement options.

## 6 Specification

INPUTS	
<b>System</b>	3 Phase 3 or 4 Wire Unbalanced Load
<b>Voltage Un</b>	400/230V. 3 Phase 3 or 4 Wire 110/63V & 208/120V optional. Others to order.
<b>Current Sensors</b>	
<b>Output @ Nominal In</b>	0.333Vac
<b>Accuracy</b>	±1% (0.1In – 1.2In)
<b>ND SCL8-5</b>	In = 5A; Max Cable = 8mm Dia. Phase Error <2.5° at 0.5In
<b>ND SCL16-50</b>	In = 50A; Max Cable = 16mm Dia. Phase Error <2.5° at 0.5In
<b>ND SCL16-100</b>	In = 100A Max Cable = 16mm Dia. Phase Error <2° at 0.5In
<b>ND SCT19-150</b>	In = 150A Max Cable = 19mm Dia. Phase Error <2° at 0.5In
<b>ND SCT32-400</b>	In = 400A; Max Cable = 32mm Dia. Phase Error <2° at 0.5In
<b>ND SCT51-800</b>	In = 800A; Max Cable = 51mm Dia. Phase Error <2° at 0.5In
<b>Enclosures</b>	UL94V-0
<b>Insulation</b>	>300Vrms, CAT III
<b>Environment</b>	Indoor use only (Altitude < 2000m)
<b>Measurement Range</b>	Voltage 20% to 120% Un Current 0.2% to 120%
<b>Frequency Range</b>	Fundamental 45 to 65Hz Harmonics Up to 30th harmonic at 50Hz Individual to the 15th
<b>Voltage Burden</b>	<0.1VA per phase
<b>Overload</b>	<b>Voltage</b> <i>x4 for 1 hour</i>  <b>Current</b> SCL x10 for 1min SCT19 200A Continuous SCT32 800A Continuous SCT51 2000A Continuous
DISPLAY	
<b>Type</b>	Custom, Supertwist, LCD
<b>Data Retention</b>	10 years min. Stores kWh & Meter set-up
<b>Format</b>	2 Rows x 4 Digits, 1 Row x 8 Digits + Legends
<b>Scaling</b>	Direct reading. User programmable CT & PT CT Primary programmable from 5A to 25kA VT primary programmable from 10V to 440kV
<b>Legends</b>	Wh, kWh, MWh etc. depending on user settings
AUXILIARY SUPPLY	
<b>Standard</b>	230V 50/60 Hz ±15%
<b>Options</b>	110V 50/60 Hz ±15%
<b>Load</b>	3VA max.
<b>Overload</b>	x1.2 continuous
METER ACCURACY <b>All errors ± 1 digit</b>	
<b>kWh</b>	Better than Class 1 per EN 62053-21 & BS 8431
<b>Kvarh</b>	Better than Class 2 per EN 62053-23 & BS 8431
<b>kW &amp; kVA</b>	Better than Class 0.25 IEC 60688
<b>kvar</b>	Better than Class 0.5 IEC 60688
<b>Amps &amp; Volts</b>	Class 0.1 IEC 60688 (0.01In – 1.2In or 0.1Un – 1.2Un)
<b>PF</b>	±0.2° (0.05In – 1.2In and 0.2Un – 1.2Un)
<b>Neutral Current</b>	Class 0.5 IEC 60688 (0.05In – 1.2In)

<b>OVERALL METERING ACCURACY</b>		
<b>ND SCL8-5</b>	<b>5 Amp</b>	Better than Class 2 Meter with Class 1 CTs
<b>ND SCL16-50</b>	<b>50 Amp</b>	Better than Class 1 Meter with Class 1 CTs
<b>ND SCL16-100</b>	<b>100 Amp</b>	Better than Class 1 Meter with Class 1 CTs
<b>ND SCT19-150</b>	<b>150 Amp</b>	Better than Class 1 Meter with Class 1 CTs
<b>ND SCT32-400</b>	<b>400 Amp</b>	Better than Class 1 Meter with Class 1 CTs
<b>ND SCT51-800</b>	<b>800 Amp</b>	Better than Class 1 Meter with Class 1 CTs
<b>PULSE OUTPUTS</b>		
<b>Function</b>	1 Pulse per unit of energy	
<b>Scaling</b>	Settable between 1 & 1000 counts of energy register	
<b>Pulse Period</b>	0.1 sec. default; Settable between 0.1 and 20 sec	
<b>Rise &amp; Fall Time</b>	< 2.0ms	
<b>Type</b>	N/O Volt free contact. Optically isolated BiFET	
<b>Contacts</b>	100mA ac/dc max ; 100V ac/dc max ; 5W maximum load	
<b>Isolation</b>	2.5kV 50Hz 1 minute	
<b>MODBUS® Serial Comms (Option)</b>		
<b>Bus Type</b>	RS485 2 wire + 0v. ½ Duplex, ¼ unit load	
<b>Protocol</b>	MODBUS® RTU with 16 bit CRC	
<b>Baud Rate</b>	4800, 9600 or 19,200 User settable	
<b>Address</b>	1 – 247 User settable	
<b>Latency</b>	Reply within 250ms max.	
<b>Command Rate</b>	New command within 5ms of previous one	
<b>GENERAL</b>		
<b>Temperature</b>	Operating -10°C to +65°C Storage -25°C to +70°C	
<b>Humidity</b>	< 75% non-condensing	
<b>Environment</b>	IP54 standard, IP65 optional	
<b>MECHANICAL</b>		
<b>Terminals</b>	Rising Cage. 4mm <sup>2</sup> (12 AWG) cable max.	
<b>Enclosure</b>	DIN 43700 96 x 96	
<b>Material</b>	Mablex® with fire protection to UL94-V-O. Self extinguishing	
<b>Dimensions</b>	96 x 96 mm x 83.5 mm (72 mm behind panel)	
<b>Weight</b>	~ 250 gms	
<b>SAFETY</b>		
<b>Conforms to</b>	EN 61010-1 Installation Category III & BS 8431	

E. & O. E.

© Northern Design (Electronics) Ltd, April 2008